




Scintillation Detectors for Space Radiation and Dosimetry

Goal: Neutron Dosimeter



Instrument Research & Development

James Christian

August 2012

E.B. Johnson, C.M. Whitney, X.J. Chen, S.M. Vogel, E.V.D. van Loef,
R. Hawrami, J.Glodo, L.S. Pandian, K.S. Shah, T.H. Prettyman, E. Benton




PSI



OSU




Compact Dosimeter Concept



- Scintillation detector and SSPM
- Simplistic
 - Anti-coincidence (distinguished ions from n, γ)
- Scintillation material capabilities
- Neutron dose (2°) important, lots of “stuff”

Dose


- Absorbed dose (TID)
- Human-equivalent dose: Tissue and Q (quality factor)
 - Q: “legislated” relative biological effectiveness (RBE) for cancer endpoint: depends on E and LET
- Displacement Damage Dose (NIEL – non-ion. E loss)





- Identify Particle Type
- Linear Energy Transfer ($LET = \left(\frac{dE}{dx} \right)$) or E
- (Dose rate)

S. Messenger, SPENVIS
Workshop 2005

Interactions with H_nC_m Scintillator




$$\frac{dL}{dx} = \frac{S \cdot \left(\frac{dE}{dx} \right)}{1 + kB \cdot \left(\frac{dE}{dx} \right) - C \cdot \left(\frac{dE}{dx} \right)^2}$$





- DPA is a “new” H₁₈C₂₆ material (~tissue density)
- Light \propto Absorbed Dose TID: Birks legacy (S & kB quenching)
- Recoil proton (in plastic) related to neutron energy

Proportionality with gammas: S-term



- S-term related to gamma ray energy resolution
- ~15 k photons per MeV (bright – as high as 20)


Characterize kB -term (protons)



- kB larger in DPA than EJ200 (C-term fixed)
 - More δ -ray/ionization quenching
 - Deviation not analysis (Experimental factors)



$$S \cdot \sum_i \frac{\left(\frac{dE}{dx} \right)_i}{1 + kB \cdot \left(\frac{dE}{dx} \right)_i + C \cdot \left(\frac{dE}{dx} \right)_i^2}$$

DPA emission time characteristics




- Distinguishes gammas from neutrons


DPA neutron distinction



- Different sources
- Dark noise
- Effect of DDD



DPA population plot



- Ideal beam measurement - *Optimistic* (avg. paths)
- DPA needs anti-coincidence

CLYC Scintillator

$\text{Cs}_2\text{LiYCl}_6$





4.78 MeV

940 Barns



0.62 MeV

<1 Barn




- Photon yield ~20 photons/keV
- CLYC proportional (good gamma E-resolution)

CLYC emission time characteristics




- Distinguish gammas from thermal neutrons (^3He)
- No p+ recoil, detect fast neutrons with ^{35}Cl

Measuring neutron energy with CLYC



- ^{35}Cl (n, p) reaction
- Fast Neutron Spectroscopy



Summary

- Interesting Scintillation Materials
 - Thermal and fast neutron
 - Distinguish p+, n, & γ
 - Beam results optimistic





- Compact Neutron Dosimeters and Spectrometers
 - Anti-coincident shield
 - Pulse-shape discrimination (electronics)
 - SSPM detectors: compact, high gain





Achievements

- Tested CLLBC Dosimeters at PNNL:
 - Category 1 – isotopes passed, x-ray failed
 - Category 2 – isotopes passed, x-ray “close”
- Designed Category-1 x-ray detector
- Received and tested new dosimeter chip
- Designed new compact version
- Developing HDD, SDD, assembly, testing, and QC protocols: ISO 9001 compliance
- Facilities: Constructed x-ray room, crystal preparation station, dry glove box, environmental chamber automation.
- Met with Stan Mavrogianis and Eric Daxon at HPS meeting



Space Environment

- Galactic Cosmic Rays (GCR), Solar Protons and Secondary Emission (gamma-rays, neutrons, and others)



- Neutron dose important, lots of background